

# TECHNICAL DATA SHEET.

TECHFLYA.DOC Page 1 of 2

## 1. IDENTIFICATION OF PRODUCT AND COMPANY

### 1.1 Product name : FLYAWAY

Water based non stick coating to prevent fly posting

### 1.2 Company : D Adam & Associates

17 High Cross Avenue, Melrose TD6 9SQ, Scotland, U.K

Tel: +44 1896822697, 07880 805478

[www.enviroguard-surface-protection.co.uk](http://www.enviroguard-surface-protection.co.uk)

[dougadam@globalnet.co.uk](mailto:dougadam@globalnet.co.uk)

## 2. TECHNICAL DATA

2.1 **STORAGE:** Prolonged shelf life when stored in closed containers.

2.2 **APPLICATION:** For light to moderate protection, apply a **minimum of two coats** by spray, brush or roller. For application to metal surfaces, a fine spray in two coats is recommended. On porous surfaces, apply two full coats of FlyAway.

2.3 **OVERCOATING:** Recoat when touch dry.

2.4 **DRYING TIME:** 2 to 8 hours, very dependent on the drying conditions.

2.5 **COVERAGE:** Theoretical - to 12 sq. Metres per litre.  
Practical - 6 - 12 sq. Metres per litre.

2.6 **PACK SIZE:** 5 litre, 25 litre or 200 litre drums.

2.7 **FLASH POINT:** n/a

2.8 **APPEARANCE:** When properly applied, **FLY-AWAY** is barely visible on stone, brick and other building materials. On metal and glass it dries to an opaque film.

2.9 **REMOVAL:** **FLY-AWAY** can be removed by a low pressure hot water power wash at 85°C or a proprietary wax remover.

## 3. PREPARATION

3.1 Surfaces should be clean and free from surface dirt, dust and grease.

3.2 All loose friable material should be removed and damaged areas made good.

3.3 Efflorescence and laitence should be treated as appropriate.

- 3.4 Existing mould growth should be treated and removed.
- 3.5 Where graffiti removal has been carried out, ensure that the area is well rinsed with water to remove all traces of oil or solvent

#### 4. **APPLICATION**

- 4.1 **FLY-AWAY** as supplied is ready to use,
- 4.2 Apply **FLY-AWAY** when the air and surface temperature is between 5°C and 25°C and the relative humidity between 40% and 90%.
- 4.3 For brush and roller applications, it is important to achieve a smooth, even coating. On non porous surfaces, do not overload brushes and rollers with excessive quantities of product so as to cause runs.
- 4.4 For spray application, apply evenly in a fine mist, a second coat at right angles to the first.
- 4.5 **Apply at the recommended coverage rates.,**
- 4.6 On poured concrete or textured surfaces, take care to cover all of the surface irregularities and indents.
- 4.7 After use, all equipment should be cleaned with water while still wet. Dry film can be removed with hot water.

#### 5. **POSTER REMOVAL**

- 5.1 Posters simply fall off and fly away from treated surfaces as a result of weathering, wind and rain. Self-adhesive stickers are easily peeled off without soaking or scraping. In dry climates, posters can be removed much more easily with water and a little detergent and low pressure power washing. Scraping and vigorous cleaning should be eliminated.

**Note:** **Enviroguard Flyaway** can also be used as an anti-graffiti coating on brick, concrete etc. Graffiti removal is carried out using a hot water pressure wash without a graffiti remover.

#### 6. **HEALTH AND SAFETY**

- 6.1 FlyAway is water based and is not regulated for use or transport. . Please ensure that operators read and understand the health and safety data sheet before using this material.

Revised May 2014